TIME MACHINE

Start On Time. Every Time.



\$699.99 MSRP

Model #: 1T09070

OVERALL DIMENSIONS:

H 9.5" x W 11.25" x D 16.5"

2 LOWER SHELF DIMENSIONS

H 2.25" x W 10.0" x D 15.0"

4 UPPER COMPARTMENT DIMENSIONS

H 4.25" x W 1.75" x D 7.0"

REAR STORAGE COMPARTMENT DIMENSIONS

H 3.75" x W 6.0" x D 8.0"

PREWIRED 8-PORT USB-A POWER STRIP POWER SUPPLY:

100 - 250 VAC 50/60 Hz output of up to 2.1A per port for sleep and charge. For devices with maximum power supply of 45W or less.

POWER BANKS:

65 Watt, 20,000mAh Superfast power bank with two USB output, one PD20W quick charging USB-C input/output port and one micro input port. Type-C Output: 5V=3A / 9V=2.22A / 12V=1.5A USB Output:5V=4.5A/9V=2A/12V=1.5A For At-the-Desk Charging with Chromebooks, iPads and Tablets.

May not charge laptops while in use.

CORD LENGTH: 12'

ASSEMBLED WEIGHT: 151b

What's your backup plan?

Forgetfulness is an aspect of human nature that can't always be prevented. What's your backup plan when students forget to charge devices, or forget to bring them at all?

The At-the-Desk Charging Solution for Chromebooks

Keeping portable battery banks and loaner devices in the Time Machine will minimize downtime and keep your students engaged.

Includes

Four 65 Watt, 20,000mAh superfast power banks* and four USB-C to C charging cables:

 Power banks have two USB output ports, one micro input port and one PD20W quick charging USB-C input/output port

8 PowerGistics Slide Stop Bands

6 USB-A to USB-C 2.0 angled cords**

to charge the four power banks and two devices

1USB-A 3-in-1 cord

- splits into Lightning, micro and USB-C

Key Features

Power Banks Included Four power banks will keep your students learning even when their device needs a charge.

Backup Device Shelves Have devices ready for the student who forgets to bring in a device or who's device needs repair.

User Friendly Compartments

Multiple compartments promote organization in the most user friendly orientations.

Maintenance-Free Cable Management Designed for quick return and retrieval

Designed for quick return and retrieval multiple times per day.

Locking Front Door The keyed locking front door keeps devices and power banks secure until you need them.

Locking Top Panel The removable top panel secures the power strip, power banks and cords. The neoprene top padding prevents scratches or damage to devices set on top.















844.205.1217

www.powergistics.com



chrome enterprise Partner