

FLEX20 ACCESSORIES

Accessories for the Flex20 add convenient options for storage and cleaning.

FLEX ROLLER

Model #: 1FR000

Attach to any FLEX20 Tower to make mobile. Includes rear handle bar for easier Tower navigation.


ROLLER DIMENSIONS:

H 1.50" x W 26.00" x D 29.00"

HANDLE BAR DIMENSIONS:

H 10" x W 13.5" x D 6"

WEIGHT: 14lb



20 Shelf Tower on Wheels:

Add a Flex Roller to the Tower for maximum mobility.

FLEX HEADPHONE BAR

Model #: 1FHBO

Mounting rack to hold headphones.

DIMENSIONS:

H 11.5" x W 1.0" x D 4.5"

WEIGHT: 0.5 lb



FLEX CLEANER CADDY

Model #: 1FCCO

Round shelf with bungee straps to hold cleaner bottle, wipes or like products.

DIMENSIONS:

H 5.2" x W 4.0" x D 3.3"

WEIGHT: 0.5 lb



FLEX LARGE ACCESSORY TRAY


Model #: 1FSATO

Large basket for accessory needs.

DIMENSIONS:

H 5.5" x W 11.5" x D 4"

WEIGHT: 1.0 lb



FLEX SMALL ACCESSORY TRAY

Model #: 1FSATO

Small basket for accessories.

DIMENSIONS:

H 4.75" x W 5.25" x D 3.70"

WEIGHT: 0.5 lb



Flex Roller and Flex Accessories sold separately.